



AES Technical Bulletin

AC Wiring Harness Install

Product models covered: Magnum Baby Countryside and
Magnum Winchester

Topic: This technical bulletin will be addressing how to install the
wiring harness.

Procedure: Attach the following;

Control Board	molex connector
Exhaust Fan	white wire to one lead blue wire to one lead
High Limit Snap Disk	two orange wires to both leads
Vacuum Pressure Switch	two grey wires to both leads
Proof of Fire Snap Disk	two brown wires to both leads
Auger Motor	white wire to one lead yellow wire to one lead
Room Air Fan	double white wires to one lead pink wire to one lead
Electrical Plug	double white wires towards the inside terminal black wire towards the outside terminal green wire to bottom terminal other end of green wire screwed to base of unit
Igniter	(these are not plugged into anything if there is not an igniter) red wire to one lead white wire to one lead