



## *AES Technical Bulletin*

### **Magnum Countryside Wiring Harness Install**

**Product Models covered:** Magnum Countryside 3500 series

**Topic:** This technical bulletin will be addressing how to install a wiring harness on the Magnum Countryside models.

**Procedure:** Attach the following;

Control Board	molex connector
Exhaust Fan	red wire to one lead double white wire to one lead
Auger Motor	black wire to one lead yellow wire to one lead
Hopper Switch	yellow wire to middle terminal (Normally Open 3) green wire to bottom terminal (Com 1)
Electrical Plug	orange wire to inside terminal (top, left side) double white wire to outside terminal (top, right side) green wire to bottom terminal other end of green wire screwed to base of unit
Fuel Stirrer Motor	double white wire to one lead brown wire to one lead
Bottom Sensor	blue wire to left terminal Grey (1 <sup>st</sup> ) and green (2 <sup>nd</sup> ) wires to right terminal
Middle Sensor	black and purple wires to either terminal
Top Sensor	white and green wires to either terminal