



AES Technical Bulletin

DC Wiring Harness Install

Product models covered: Magnum Baby Countryside and Magnum Winchester

Topic: This technical bulletin will be addressing how to install a wiring harness on the Magnum Baby Countryside DC and Magnum Winchester DC models.

Procedure: Attach the following;

Control Board	two molex connectors 6 prong and 8 prong
Exhaust Fan	red wire to blue wire blue wire to purple wire (depending on style of fan white wire to blue wire black wire to purple wire)
Exhaust Fan Sensor	two brown wires to both leads
Vacuum Pressure Switch	two grey wires to both leads
Auger Housing Sensor	two orange wires to both leads
Auger Motor	one yellow wire to positive lead one yellow/black wire to negative lead
Room Air Fan	red wire to pink wire black wire to double purple wire
Power Supply	green/yellow wire screw to the base of the unit. 5 prong molex connector

General: It is very critical that the wires are hooked up with the correct corresponding wires.